

**TABLE 1--ENGINE MODELS (AD 2009-26-12)**

Cylinder Assembly Part Number:	Installed on Engine Models:
AEL65102-NST04	<p><b>O-320</b>-A1B, A2B, A2C, A2D, A3A, A3B, B2B, B2C, B2D, B2E, B3B, B3C, C2B, C2C, C3B, C3C, D1A, D1AD, D1B, D1C, D1D, D1F, D2A, D2B, D2C, D2F, D2G, D2H, D2J, D3G, E1A, E1B, E1C, E1F, E1J, E2A, E2B, E2C, E2D, E2E, E2F, E2G, E2H, E3D, E3H</p> <p><b>IO-320</b>-A1A, A2A, B1A, B1B, B1C, B1D, B1E, B2A, D1A, D1AD, D1B, D1C, E1A, E1B, E2A, E2B</p> <p><b>AEIO-320</b>-D1B, D2B, E1A, E1B, E2A, E2B</p> <p><b>AIO-320</b>-A1A, A1B, A2A, A2B, B1B, C1B</p> <p><b>LIO-320</b>-B1A</p>
AEL65102-NST05	<p><b>IO-320</b>-C1A, C1B, C1F, F1A</p> <p><b>LIO-320</b>-C1A</p>
AEL65102-NST06	<p><b>O-320</b>-A1A, A2A, A2B, A2C, A3A, A3B, A3C, E1A, E1B, E2A, E2C, (also, an O-320 model with no suffix)</p> <p><b>IO-320</b>-A1A, A2A</p>
AEL65102-NST07	<p><b>IO-320</b>- B1A, B1B</p> <p><b>LIO-320</b>- B1A</p>
AEL65102-NST08	<p><b>O-320</b>-B1A, B1B, B2A, B2B, B3A, B3B, B3C, C1A, C1B, C2A, C2B, C3A, C3B, C3C, D1A, D1B, D2A, D2B, D2C</p>
AEL65102-NST10	<p><b>O-360</b>-A1A, A1C, A1D, A2A, A2E, A3A, A3D, A4A, B1A, B1B, B2A, B2B, C1A, C1C, C1G, C2A, C2B, C2C, C2D, D1A, D2A, D2B</p> <p><b>IO-360</b>-B1A, B1B, B1C</p> <p><b>HO-360</b>-A1A, B1A, B1B</p> <p><b>HIO-360</b>-B1A, B1B</p> <p><b>AEIO-360</b>-B1B</p> <p><b>O-540</b>-A1A, A1A5, A1B5, A1C5, A1D, A1D5, A2B, A3D5, A4A5, A4B5, A4C5, A4D5, B1A5, B1B5, B1D5, B2A5, B2B5, B2C5, B4A5, B4B5, D1A5, E1A, E4A5, E4B5, E4C5, F1A5, F1B5, G1A5, G2A5</p> <p><b>IO-540</b>-C1B5, C1C5, C2C, C4B5, C4B5D, C4C5, D4A5, D4B5, N1A5</p>

Cylinder Assembly Part Number:	Installed on Engine Models:
AEL65102-NST12	<p><b>O-360-</b> A1A, A1AD, A1D, A1F, A1F6, A1F6D, A1G, A1G6, A1G6D, A1H, A1H6, A1J, A1LD, A1P, A2A, A2D, A2F, A2G, A2H, A3A, A3AD, A3D, A4A, A4AD, A4D, A4G, A4J, A4JD, A4K, A4M, A4N, A4P, A5AD, B1A, B2C, C1A, C1C, C1E, C1F, C1G, C2A, C2B, C2C, C2D, C2E, C4F, C4P, D2A, F1A6, G1A6</p> <p><b>HO-360 -C1A</b></p> <p><b>LO-360-A1G6D, A1H6</b></p> <p><b>HIO-360-B1A, B1B, G1A</b></p> <p><b>LTO-360-A1A6D</b></p> <p><b>TO-360-A1A6D</b></p> <p><b>IO-360-B1B, B1BD, B1D, B1E, B1F, B1F6, B1G6, B2E, B2F, B2F6, B4A, E1A, L2A, M1A, M1B</b></p> <p><b>AEIO-360-B1B, B1D, B1E, B1F, B1F6, B1G6, B1H, B2F, B2F6, B4A, H1A, H1B</b></p> <p><b>O-540-A4D5, B2B5, B2C5, B2C5D, B4B5, B4B5D, E4A5, E4B5, E4C5, G1A5, G2A5, H1A5, H1A5D, H1B5, H1B5D, H2A5, H2A5D, H2B5D</b></p> <p><b>IO-540-C4B5, C4B5D, C4D5, C4D5D, D4A5, D4B5, D4C5, N1A5, N1A5D, T4A5D, T4B5, T4B5D, T4C5D, V4A5, V4A5D</b></p> <p><b>AEIO-540-D4A5, D4B5, D4C5, D4D5</b></p>
AEL65102-NST26	<p><b>IO-540-J4A5, R1A5</b></p> <p><b>TIO-540-C1A, E1A, G1A, H1A</b></p>
AEL65102-NST38	<p><b>IO-360-F1A</b></p> <p><b>TIO-540-AA1AD, AB1AD, AB1BD, AF1A, AG1A, AK1A, C1A, C1AD, K1AD</b></p> <p><b>LTIO-540-K1AD</b></p>
AEL65102-NST43	<p><b>O-360-J2A</b></p> <p><b>O-540-F1B5, J1A5D, J1B5D, J1C5D, J1D5D, J2A5D, J2B5D, J2C5D, J2D5D, J3A5, J3A5D, J3C5D</b></p> <p><b>IO-540-AB1A5, W1A5, W1A5D, W3A5D</b></p>
AEL65102-NST44	<b>O-540-L3C5D</b>